

**ATM-T Series**  
**5 DIGITAL MICROPROCESS**  
**TEMPERATURE**  
**(THERMOCOUPLE) ISOLATED**  
**TRANSMITTER**

**USER'S MANUAL (V1.1)**

**健昇科技股份有限公司**

**JS AUTOMATION CORP.**

新北市汐止區中興路 100 號 6 樓

6F., No.100, Zhongxing Rd.,

Xizhi Dist., New Taipei City, Taiwan

TEL : +886-2-2647-6936

FAX : +886-2-2647-6940

<http://www.automation.com.tw>

<http://www.automation-js.com/>

E-mail : [control.cards@automation.com.tw](mailto:control.cards@automation.com.tw)

## Correction record

Version	Record
V1.1	Modify 10. Ordering information

# Contents

1. Features.....	3
2. Specifications.....	3
3. Front panel & Key functions .....	4
4. General Mode Operating Procedures.....	5
5. Programming Mode Operating Procedures .....	6
6. Error Code of Self-Diagnosis .....	7
7. Calibration Operating Procedures.....	7
8. Dimensions .....	8
9. Wiring Connection.....	8
10. Ordering information .....	9


## 1. Features

- Versatile output selection : 4~20mA , 0~20mA , 0~5V , 0~10V
- Accuracy :  $\pm 0.2\%$  F.S.,  $\pm 0.5$  degree C (cold junction compensation)
- Measuring Temperature (TC) sensors for K, J, E, R, S, B, T types
- Measuring sensors disconnection
- 1 decimal point selectable
- Degree C / degree F units selectable
- 1 control output: ON/OFF proportion programmable
- High stability, non-flammable case (PC), high safety

## 2. Specifications

- Output selection : 4~20mA , 0~20mA , 0~5V , 0~10V
- Accuracy :  $\pm 0.2\%$  F.S.,  
 $\pm 0.5$  degree C (cold junction compensation)
- Display Screen : High brightness red LED; 10.16mm(0.4")
- Parameters Setting : Push buttons
- Back Up Memory : EEPROM
- Over Range Indication : doFL/ioFL or -doFL/-ioFL
- Disconnection Indication : Automatic with "OPEN" indication
- Analog Output Resolution : 15 bit
- Output Ripple :  $\leq \pm 0.1\%$  F.S.
- Output Response Time : < 250 msec (0~90%)
- Output Capability : Voltage Output: < 20mA  
Current Output: < 10V
- Isolation : Input / Output / Power / Case
- Insulation Resistance : > 100M $\Omega$  with 500Vdc
- Surge Test : 2KVac/1min
- Input Impedence : Voltage: > 2V for 20K $\Omega$ /V;  $\leq 2$ V for > 200M $\Omega$   
Current:  $\geq 0.2$ A at 100mV; < 0.2A at 1V
- Temperature Coefficient : 100ppm/degree C (0~60 degree C )
- Operating Temperature : 0-60 degree C
- Operating Humidity : 20 to 90% RH (non-condensing)
- Storage Temperature : -10-70 degree C
- Storage Humidity : 20 to 90% RH (non-condensing)
- Power Supply : AC 110, AC 220V
- Installation : Socket / Plug-in

### 3. Front panel & Key functions



Key Name	Symbol	Descriptions
Enter Key & Save Key	<b>ENT</b>	1. In the measuring status, press this key can enter to parameter pages. 2. In the parameter setting, press this key can save the value & go to next page.
Shift Key	⇐	1. In the parameter setting , press this key can move the cursor left.
Up Key & Display Value Adjusting Key	↑	1. In the measuring status, press this key for 3 sec can enter to display adjustment of "ZERO" & "SPAN" 2. In the parameter setting, press this key can increase the digits.
Down Key & A/O Adjusting Key	↓	1. In the measuring status, press this key for 3 sec can enter to analog output adjustment. 2. In the parameter setting , press this key can decrease the digits.

1. The following block charts are parameters codes, parameter codes & parameters will alternate flashing if the parameters can be modified.
2. To modify the parameters, please press ⇐ ↑ ↓ , and press ENT to save the parameters after the modification.
3. Please don't forget the new pass code after modification.
4. In any pages, pres ↑ & ↓ , or don't press any keys for 2 minutes that will back to measuring status.







## 4. General Mode Operating Procedures

Block Charts	Display	Descriptions	Default
		<b>Display : "ZERO" &amp; "SPAN" Adjustment</b>	
<pre> graph TD     PO([Power On]) --&gt; D1[10000]     D1 -- "Press ← for 3 sec" --&gt; D2[dZEro]     D2 -- "Press ENT" --&gt; D3[dSPANn]     D3 -- "Press ENT" --&gt; D4[10000]     D4 -.-&gt; A1[10000]     </pre>	Measuring Status	Present value for measurement.	
	Display (dZEro)	Press ⇐ to select adjusting speed rate, press ↑ ↓ to modify the zero value.	00000
	Adjustment (dZEro)	PS: To use this function to adjust the real zero value.	
	Display Span Adjustment (dSPAN)	Press ⇐ to select adjusting speed rate, press ↑ ↓ to modify the span value.	00000
	Adjustment (dSPAN)	PS: To use this function to adjust the real span value.	
		<b>Analog Output: "ZERO" &amp; "SPAN" Adjustment</b>	
<pre> graph TD     A1[10000] -- "Press → for 3 sec" --&gt; A2[AZEro]     A2 -- "Press ENT" --&gt; A3[ASPAAn]     A3 -- "Press ENT" --&gt; A4[10000]     </pre>	Measuring Status	Present value for measurement.	
	A/O Zero Adjustment (AZero)	Press ⇐ to select adjusting speed rate, press ↑ ↓ to modify the A/O zero.	00000
	Adjustment (AZero)	PS: To use this function to adjust the real A/O zero.	
	A/O Span Adjustment (ASPAAn)	Press ⇐ to select adjusting speed rate, press ↑ ↓ to modify the A/O span.	00000
Adjustment (ASPAAn)	PS: To use this function to adjust the real A/O span.		

## 5. Programming Mode Operating Procedures


Block Charts	Display	Descriptions	Default
	Measuring Status	Present value for measurement.	
	Pass Code (P.Cod)	Press ⏪ ⏩ ⏴ to enter pass code.	<b>00000</b>
		Pass code is correct that will enter to parameter groups. Pass code is wrong that will back to measuring status.	
	System Setting Page (SYS)	Press ⏪ can select A/O setting page.	
	Input Type Setting (tYPE)	Pass ⏩ ⏴ to modify the input type.	
	Decimal Point Setting (dP)	Pass ⏩ ⏴ to select decimal point (0, 1). EX: if the value shows "0.0" that means the decimal point is 1 digit.	<b>00000</b>
	Temperature Unit Setting (Unit)	Pass ⏩ ⏴ to modify the unit of linear-speed (°C/°F).	<b>0C</b>
	Cold Junction Compensation (CJC)	Pass ⏩ ⏴ can switch (on) or (off) cold junction compensation.	<b>no</b>
	Display Average Setting (AvG)	Pass ⏪ ⏩ ⏴ to modify display average (1~99). PS: Please use this function for stable display value when input signal is unstable.	<b>00020</b>
	Pass Code Setting (CodE)	Pass ⏪ ⏩ ⏴ to modify pass code (0~19999). PS: Please don't forget the new pass code after modification.	<b>00000</b>
	Key Lock Setting (LoCK)	Pass ⏩ ⏴ to lock the keys, using key lock function only can view the parameters, but cannot modify any values. PS: no (unlock) ,YES ("ENT" unlock , others lock).	<b>no</b>
	A/O Setting Page (AoP)	Pass ⏪ can select A/O setting page.	
	A/O Polarity Setting (PoLAr)	Pass ⏪ ⏩ ⏴ To modify output is positive pole or negative pole. PS : Voltage output ,NO: positive pole output (0~+10V) YES: positive & negative pole output (-10~+10V)	<b>no</b>
	A/O Low Scale Setting (AnLo)	Pass ⏪ ⏩ ⏴ to adjust A/O low scale to correspond to the display value. EX : A/O is 0~10V, the display is 10.0 to output 0V, this value must be set for 10.0.	<b>00000</b>
A/O Hi Scale Setting (AnHi)	Pass ⏪ ⏩ ⏴ to adjust A/O hi scale to correspond to the display value. EX : A/O is 0~10V, the display is 90.0 to output 10V, this value must be set for 90.0.	<b>99999</b>	

## 6. Error Code of Self-Diagnosis

Display	Descriptions
	Cold junction is over sensor's (PT100) measuring range (0~100°C).
	Cold junction is under sensor's (PT100) measuring range (0~100°C).
	Input signal or cold junction is disconnection.
	Input signal is over sensor's (T.C) measuring range.
	Input signal is under sensor's (T.C) measuring range.
	EEPROM reading/writing suffers the interference (about 1 million times).

※Please check the wiring connection is correct first, if the problem still exist, please return the meter to the factory.


## 7. Calibration Operating Procedures

	Display	Descriptions	Default
	Measuring Status	Present value for measurement Press ENT & ← together for 3 sec will enter to calibration operating procedures.	
	Input Low Scale Calibration (inLo)	1. Input standard low scale signal. 2. Press ← ↑ ↓ to calibrate input low scale.	
	Input Hi Scale Calibration (inHi)	1. Input standard hi scale signal. 2. Press ← ↑ ↓ to calibrate input hi scale	
	System Setting Page (SYS)	1. Finish calibration operating procedures will enter to system setting group. 2. Press ↑ & ↓ together to back to measuring status.	


Warning: Calibration of this meter requires a standard signal with 0.01% accuracy or better and an external meter with 0.005% accuracy or better.



## 8. Dimensions



## 9. Wiring Connection



## 10. Ordering information

